

**KENT**  
Smart Chef  
Appliances  
HOUSE of PURITY



Imported & Marketed by:  
**KENT RO SYSTEMS LTD.**  
E-6, 7 & 8, Sector-59, Noida, U.P.-201 309, India. Call: 92-789-12345  
For customer complaints, contact our Customer Care Officer at:  
E-6, 7 & 8, Sector-59, Noida, U.P.-201 309, India. Call: 92-789-12345  
E-mail: [service@kent.co.in](mailto:service@kent.co.in) or visit us at [www.kent.co.in](http://www.kent.co.in)  
Made in People's Republic of China

## KENT Cool Touch Glass Kettle

**KENT**  
Smart Chef  
Appliances  
HOUSE of PURITY



High borosilicate  
glass body  
for hygiene



LED to indicate  
'switch-on'  
mode



Automatically  
switches off  
after boiling



Protection  
from  
Dry-boiling

1.8L  
Capacity



1500 W Power



# Welcome to KENT

Dear Customer,

Congratulations on your purchase and welcome to KENT!

At the outset, allow us to thank you for your trust in KENT Smart Chef Appliances. At KENT, we take pride in our reputation for quality products and industry proven performance. We are certain that you will be more than satisfied with KENT Cool Touch Glass Kettle performance and that it will serve you and your family's need without any compromise.

This guide will help you in getting the best out of your appliance. Please go through the booklet to familiarize yourself with the operation and maintenance.

With the robust build and high quality, you can look forward to years of trouble-free service.

To ensure that the warranty of your appliance is effective, it is important that you fill up the enclosed warranty card and mail it to us within 15 days of purchase.

In case you require any further information, please contact your nearest KENT dealer or branch.

Bon Appétite!

**KENT RO Systems Ltd.**

## TABLE OF CONTENTS

1. Introduction .....	1
2. Features of KENT Cool Touch Glass Kettle .....	1
3. Know Your Product .....	2
4. Using KENT Cool Touch Glass Kettle .....	2
5. Procedure for Using KENT Cool Touch Glass Kettle .....	3
6. Cleaning and Maintenance .....	3
7. How To Eliminate Scale .....	4
8. Precautions .....	4
9. Troubleshooting .....	5
10. Technical Specifications .....	6

## INTRODUCTION

We, at KENT have always believed that a clean and healthy life is the right of every individual. This ethos is what made us embark on the journey to develop innovative solutions for purifying the water that we drink, vegetables and fruits that we eat, the homes we live in and the air that we breathe.

Our use of innovative technology, supported by a competent service network, has enabled us to create a brand, which has become synonymous to well-being. Continuing with the tradition, we now present the all-new KENT Cool Touch Glass Kettle, a modern day appliance for boiling water.

KENT Cool Touch Glass Kettle comes with a flat heating plate for efficient heat distribution. The bottom mounted heating plate allows 360° rotation for ease of use.

## FEATURES OF KENT COOL TOUCH GLASS KETTLE

1. Cool touch outer cover, aesthetically covering the body.
2. High Borosilicate glass body for hygiene.
3. Blue indicator light that indicates the device is ON.
4. Blue ambient light inside the kettle, when device is turned ON.
5. 1500 Watt power consumption with large capacity of 1.8 Ltrs.
6. 360° rotation base for ease of use.
7. Water level indicator.

## KNOW YOUR PRODUCT



## USING KENT COOL TOUCH GLASS KETTLE

- Remove any stickers that might prevent from operating the unit.
- Check the unit for damages. Do not use in case of any damages.
- Before switching on the appliance, make sure that your home mains voltage corresponds to the unit's operating voltage.
- Clean the parts of the KENT Cool Touch Glass Kettle before using the appliance for the first time (see 'Cleaning & Maintenance' section).
- Make sure all parts are completely dry before you start using the appliance.
- Fill the kettle with normal water to the maximum fill mark. Do not over fill.
- Close the lid, place the kettle over the power base and switch it on.

## PROCEDURE FOR USING KENT COOL TOUCH GLASS KETTLE

- Fill the kettle with normal water to the desired level and close the lid. Do not over fill. To prevent dry-boiling, please fill at-least 250 ml or one cup.
- Place the kettle on the power base.
- Plug in and switch on the kettle.
- The Blue LEDs will light up.
- The water will start boiling in some time. Do not open the lid while water is boiling.
- Once the water has boiled, the kettle will automatically switch off.
- If boiled water is not required immediately, you may leave the kettle on the base and bring it to boil again later.
- Always ensure to turn off the kettle before lifting the kettle.

## CLEANING & MAINTENANCE

- Please unplug the power plug and let the pot cool down before cleaning.
- Please wipe the kettle body with a damp cloth. Do not use scouring powder or cleaning ointment products; they will damage the surface characteristics of kettle.
- If required, use a mild detergent to remove stains.
- Do not use any abrasive or solvent based cleaner.
- Do not immerse the kettle, power cord, power plug and power socket into the water.
- Do not immerse the appliance & power base in water or any other liquid.

## HOW TO ELIMINATE SCALE

To keep the kettle in good working order, the scale must be removed frequently. If the outage occurs while working, it indicates that the kettle's scale has to be cleared. Please use the following methods to clear the scale:

1. Please use a dedicated product that can effectively remove the scale and follow the product directions.
2. Please pour 0.5 litres of white vinegar into the kettle and soak it for an hour. After that, drain the white vinegar and wash it 4-5 times with clean water.
3. Please fill the kettle with 0.5 litres of water and bring it to a boil, then add 25 grams of citric acid, soak for 15 minutes, then wash it 4-5 times with clean water.

## PRECAUTIONS

- Do not disassemble, repair or alter the machine on your own. It may cause appliance failure or breakdown.
- The input voltage must not exceed the rating; it might damage the appliance.
- Unplug before cleaning/moving the appliance.
- Do not use the appliance with damaged power cord or plug.
- If power cord is damaged, replace it with a genuine KENT spare.
- Do not install the machine near any heat source, e.g., heater.
- If the appliance is not in use for a longer time, unplug it.
- Do not sit on, stand on or shake the appliance.
- Do not use the appliance when it is in a recumbent or inclined position.

## TROUBLESHOOTING

PROBLEM	SOLUTION POSSIBLE
It shuts down without boiling the water.	1. It can be resolved by clearing the scale.
	2. The following actions should be followed to re-set the dry boiling protection devices if the kettle is empty or has insufficient water in it. Once more, we fill the pot with cold water. After roughly two minutes, the dry burning prevention device will be relaxed, allowing the kettle to operate.
The kettle does not work.	1. Please check whether plug and the socket are connected.
	2. Switch off the appliance and unplug it. Go to the nearest KENT authorized service centre for assistance.

There is a peculiar smell in the water.	1. This usually happens when the kettle is used for the first time. Wash the kettle properly before using it.
	2. If this problem persists, add water to the pot to the maximum level, add two spoonfuls of baking powder to the water, and then drain the water after boiling.
There is dirty water or water scale inside the kettle.	1. Since the local water can often be hard, due to the presence of calcium carbonate and magnesium carbonate, just clear the scale in time.

## TECHNICAL SPECIFICATIONS

<b>Product</b>	<b>KENT COOL TOUCH GLASS KETTLE</b>
<b>Product Code</b>	116136
<b>Capacity</b>	1.8 L
<b>Net Weight</b>	1.1 kg
<b>Max Power</b>	1500 W
<b>Input Power Supply</b>	Single Phase 220 – 240 V AC, 50-60Hz. 