

**KENT**   
**NutriMix**

A SMARTER & QUICKER  
WAY OF EVERYDAY COOKING

Instruction Manual



**KENT**  
*Smart Chef*  
Appliances  
HOUSE of PURITY

**300**   
**WATT**

500ml Blending Jar

300ml Grinding Jar



 **JARS**

- 500ml Blending Jar
- 300ml Grinding Jar



# Welcome to KENT

Dear Customer,

Congratulations on your purchase and welcome to **KENT**.

At the outset, allow us to thank you for your trust in **KENT Smart Chef Appliances**. At KENT, we take pride in our reputation for quality products and industry proven performance. We are certain that you will be more than satisfied with **KENT NutriMix** performance and that it will serve you and your family without any compromises.

This guide will help you in getting the best out of your appliance. Please go through the booklet to familiarize yourself with its operation and maintenance.

With the robust build and high quality, you can look forward to years of trouble-free service.

To ensure that the warranty of your appliance is effective, it is important that you fill up the enclosed warranty card and mail it to us within 15 days of purchase.

In case you require any further information, please contact your nearest **KENT** dealer / branch.

Bon Appétit!

**KENT RO Systems Ltd.**

## TABLE OF CONTENTS

1. Introduction.....	1
2. Features of KENT NutriMix.....	1
3. Know Your Product.....	1
4. Items in the Box.....	2
5. Using KENT NutriMix.....	2
6. Operating Modes.....	2
7. How to Operate.....	3
8. Cleaning and Maintenance.....	3
9. Precautions.....	3
10. Important Safety Instructions.....	4
11. Troubleshooting.....	5
12. Technical Specifications.....	6

## INTRODUCTION

We at KENT, have always believed that a clean and healthy life is the right of every individual. This ethos is what made us embark on the journey to develop innovative solutions for purifying the water that we drink, vegetables and fruits that we eat, homes that we live in and the air that we breathe.


Use of innovative technology and support from a competent service network have enabled us to create a brand, which has become synonymous to well-being and health. Continuing with the tradition, we now present the **KENT NutriMix**, a new age, high-speed portable blender that works like magic.

A delightful cooking experience awaits you with **KENT NutriMix**. Powered by 300W motor, it comes with 2 jars and high-quality stainless-steel blades for smooth blending, mixing, and grinding. Whether it is crushing ice or preparing smoothies full of nutrients, you can do it in a jiffy. Moreover, it can effortlessly grind masalas, powder coffee beans and make the yummiest chutneys. Make everyday cooking a lot smarter and a lot healthier with KENT.

## FEATURES OF KENT NutriMix

- Single High-speed operation
- High food grade quality jars with SS blades for hygienic operation and durability
- Spill-proof lockable jars
- Ideal for blending fruits and vegetables, grinding spices and chutneys
- Break-resistant polycarbonate jars

## KNOW YOUR PRODUCT



## ITEMS IN THE BOX

1. KENT NutriMix : 1 N
2. 500ml Blending Jar : 1 N
3. 300ml Grinding Jar : 1 N
4. Warranty Card : 1 N

## KENT NutriMix

1. Remove any stickers that might prevent from operating the unit
2. Check the unit for damages. Do not use in case of any damages
3. Before switching on the appliance, make sure that your home's mains voltage corresponds to the unit's operating voltage
4. Clean the parts of the KENT NutriMix before using the appliance for the first time (see 'Cleaning & Maintenance' section)
5. Make sure all parts are completely dry before you start using the appliance

## OPERATING MODES

	
<b>BLENDING MODE</b>	<b>GRINDING MODE</b>
Ideal for: <ul style="list-style-type: none"><li>• Purees</li><li>• Milkshakes</li><li>• Smoothies</li><li>• Juices</li></ul>	Ideal for: <ul style="list-style-type: none"><li>• Cereals</li></ul>

## HOW TO OPERATE

### Blending Mode

1. Unlid the blender jar and add the ingredients in the jar
2. Add milk or water as per the taste or requirement
3. Secure the blender blade assembly tightly in place on the jar
4. Turn the jar upside down and place it on the motor base unit
5. Turn the appliance on
6. Once done, switch off the appliance and unmount the jar.
7. Replace the juicer blade assembly with a normal lid and keep in fridge for later use

### Grinding Mode

1. Unlid the grinding jar and add the ingredients
2. Secure the lid tightly
3. Turn the jar upside down and place on the motor base kept on a firm place
4. Switch on
5. Once done, switch off the appliance. Turn counter clockwise and unmount the grinding jar

## CLEANING & MAINTENANCE

- Switch off and unplug the appliance before cleaning it
- Remove the lid and clean the blender jar with a solution of lukewarm water & soap
- Use a cleaning brush, never use scorching pads to clean it
- Wipe the main unit with a moist cloth and a non-abrasive liquid cleaner
- Do not immerse the appliance in water or any other liquid
- Never put any part of the appliance in the dishwasher
- After cleaning it thoroughly, dry it using a soft cloth
- Ensure that the appliance is completely dry before storing it

**Note:** Never immerse the motor unit of the blender in water, nor rinse it under the tap. Wipe it with a dry cloth.

## PRECAUTIONS

- Do not disassemble, repair or alter the appliance on your own. It may cause appliance failure or breakdown
- The input voltage must not exceed the rating, it might damage the appliance

- Unplug before cleaning / moving the appliance
- Do not use the appliance with a damaged power cord or plug
- Do not use the appliance near any heat source
- If the appliance is not in use for a longer time, unplug it
- Do not use the appliance when it is in a recumbent or inclined position

## IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

1. Unplug when not when not in use and before servicing
2. To reduce the risk of an electric shock, do not use near or on wet surfaces
3. Use the appliance only as described in the manual
4. Do not use the appliance if cord or plug is damaged or worn out. Replace the damaged cord or plug immediately
5. Do not try to service the appliance on your own. Send it to an authorized service center only
6. Keep cord away from heated surfaces
7. Do not unplug the appliance by pulling the cord. Always unplug by pulling the plug
8. To avoid electric shocks, do not use the appliance with wet hands
9. Keep hair, loose clothing, fingers and all parts of body away from moving parts
10. Turn all controls off before unplugging
11. This appliance is suitable for indoor use only
12. Keep away from children

## TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
The appliance does not start.	There is a connection problem.	Check if the appliance is connected to the mains and if the plug is inserted firmly into the wall socket.
	The appliance is defective.	Switch off the appliance and unplug it. Go to the nearest KENT authorized service centre for assistance
The appliance suddenly stops working while running.	The appliance has overheated.	Let the appliance cool for 20 minutes before attempting to restart it.
	The appliance is overloaded.	Remove some ingredients, add some water and try again.
	The appliance is defective.	Switch off the appliance and unplug it. Go to the nearest KENT authorised service centre for assistance.
The appliance makes lots of noise.	Jar is not placed properly.	Reposition the jar in the correct position.
	Blades not working properly.	Reinstall the blades correctly. If problem persists, replace blades.
	Problem with blender's inner drive broken.	Switch off the appliance and unplug it. Go to the nearest KENT authorised service centre for assistance.
Motor does not work properly.	Appliance is defective.	Switch off the appliance and unplug it. Go to the nearest KENT authorised service centre for assistance.
	Blades are not installed properly.	Reinstall the blades correctly. If problem persists, replace blades.



## TECHNICAL SPECIFICATIONS

<b>Product</b>	<b>KENT NutriMix</b>
<b>Product Code</b>	16120
<b>Product Generic Name</b>	Mixer & Blender
<b>Product Colour</b>	Black
<b>Net Weight</b>	1.130 kg
<b>Blending Jar Capacity</b>	500 ml
<b>Grinding Jar Capacity</b>	300 ml
<b>Input Power Supply</b>	Single Phase 230 V AC, 50 Hz.
<b>Total Power Consumption</b>	300 W



HOUSE of PURITY



Innovations for  
Better Living

Marketed by:

**KENT RO SYSTEMS LTD.**

E-6, 7 & 8, Sector-59, Noida, U.P.-201 309, India.

E-mail: [sales@kent.co.in](mailto:sales@kent.co.in)

Manufactured by:

**KANZ ELECTRICAL INDUSTRIES**

16, Himuda Ind Area, Phase IV, Bhatoli Kalan,

Baddi, Himachal Pradesh. India

**For customer complaints,  
contact our Customer Care Officer at:**

E-6, 7 & 8, Sector-59, Noida, U.P.-201 309, India.

Call: 92-789-12345

E-mail: [service@kent.co.in](mailto:service@kent.co.in) or visit us at [www.kent.co.in](http://www.kent.co.in)