

# KENT ULTIMA VEGETABLE CLEANER

Removes Pesticides, Bacteria, Viruses & Chemicals  
With Detachable Container

**KENT**  
*Vegetable*  
**Cleaner**  
HOUSE of PURITY

**KENT**  
*Vegetable*  
**Cleaner**  
HOUSE of PURITY

## Instruction Handbook for Installation, Operation and Maintenance



**Marketed by:**

**KENT RO SYSTEMS LTD.**

E-6, 7 & 8, Sector-59, Noida, U.P.-201 309, India.

E-mail: [sales@kent.co.in](mailto:sales@kent.co.in) | Website: [www.kent.co.in](http://www.kent.co.in)

**Manufactured by:**

**KENT RO SYSTEMS LTD.**

1) Khasra No.93, Village-Bantakhedi, Tehsil-Roorkee,  
District-Haridwar, Uttarakhand-247 668, India.

2) A-6, Sector-87, Noida-201 305, U.P., India.

3) A-7, Sector-87, Noida-201 305, U.P., India.

**For customer complaints, contact Customer Care Officer at:**

E-6, 7 & 8, Sector-59, Noida, U.P.-201 309, India. Call: 92-789-12345

E-mail: [service@kent.co.in](mailto:service@kent.co.in) or Visit us at [www.kent.co.in](http://www.kent.co.in)



# Welcome to KENT

Dear Customer,

Congratulations on your purchase and welcome to KENT.

At the outset, allow us to thank you for your trust in KENT Ultima Vegetable Cleaner. At KENT, we take pride in our reputation for quality products and industry-proven performance. We are certain that you will be more than satisfied with the performance of KENT Ultima Vegetable Cleaner and that it will serve you and your family's need without any compromise.

This guide will help you in getting the best out of your appliance. Please go through the booklet to familiarize yourself with operation and maintenance.

With its robust quality, you can look forward to years of trouble-free service.

In case you require any further information, please contact your nearest KENT dealer or branch.

Bon Appetite!

KENT RO System Limited

## Table of Contents

1. KENT Ultima Vegetable Cleaner	1
2. Know Your Product	1
3. Items in the Box	1
4. Salient Features	1
5. Installation Guidelines	2
6. Usage Guidelines	2
7. Maintenance	3
8. Ozone Time Setting Chart	4
9. Troubleshooting	5
10. Caution	5
11. Technical Specifications	6

## KENT Ultima Vegetable Cleaner

The KENT Ultima Vegetable Cleaner is an excellent ozonator which removes pesticides, bacteria, viruses and harmful chemicals from the surface of vegetables, fruits, sea food, meat, rice and other eatables, making them fresh and pure.

### Know Your Product



### Items in the Box


- |                                      |   |     |
|--------------------------------------|---|-----|
| 1. The KENT Ultima Vegetable Cleaner | : | 1 N |
| 2. Silicon Rubber Tube               | : | 1 N |
| 3. Sticker Central Drill             | : | 1 N |
| 4. Bubble Stone                      | : | 2 N |
| 5. Screws                            | : | 2 N |
| 6. Warranty Card                     | : | 1 N |

### Salient Features

- Counter Top/Wall Mountable
- Sleek and modern design
- No consumables required
- Easily cleans vegetables & fruits
- Easy-to-clean detachable tank
- Oxidises residual chemicals from surface of vegetables and fruits
- Does not require any service and change of parts
- Works on bio-friendly Ozone Technology

## Installation Instructions

1. KENT Ultima Vegetable Cleaner can be placed on a table or mounted on a wall.
2. Select an appropriate position for the device.
3. Paste the central drill sticker on wall (3.6 feet to 4.0 feet from the ground) as per your convenience.
4. Ensure that sticker is pasted straight on the wall, then drill holes as per the space provided on sticker.
5. Now insert the puff up (screw) bolt and screw in the hanging board on the wall.
6. Screw in two 10x50 self-taping screws, 5.57 inches (141.5 mm) apart horizontally.
7. Place the device on hanging board hangers and ensure that it is in a balanced position.
8. The device is now ready for use.
9. The system and installation needs to comply with state and local laws and regulations.
10. Connect the power supply.
11. Installation is complete.



**Note:** If the wall is not straight or the screws are not properly drilled in an even position, it will damage your Vegetable Cleaner.

**Note:** Keep the device away from heat or direct sunlight.

## Usage Guidelines

**Step 01:** Fill the detachable tank with water and the vegetables/fruits to be cleaned. While vegetables and fruits could be cleaned together, do not mix vegetables and meat based products for cleaning.

**Step 02:** Dip the silicon tube with stone attached to its end in the detachable tank.

**Step 03:** Insert the main plug into the power socket and switch on the power supply.

**Step 04:** Switch on the machine by turning on power switch (ON/OFF button). The LED light flashes to indicate that the device is ready to be used.

**Step 05:** Set the appropriate time (15 or 30 minutes) depending upon the items to be cleaned (Refer chart for further clarification). For meat based products, the applicable time is 30 minutes.

**Step 06:** The device will automatically stop after the expiry of the set time. Once the device has stopped, remove the stone and throw away the water in the detachable tank.

**Step 07:** Wash the vegetables/fruits in fresh water.


**Step 08:** The cleaned vegetables/fruits are now ready for consumption. If the cleaned items are not to be consumed immediately, wipe them dry with a clean napkin or tissue paper and store them for consumption later.

**Note:** If the quantity is large, keep the timer set for 30 minutes.

## Maintenance

To ensure that the Vegetable Cleaner operates at its BEST, routine maintenance must be performed.

- Storage tank must be cleaned once in 2 weeks (Refer cleaning the water tank)
- In the event of not using Vegetable Cleaner for a long time (while going for a holiday, tour etc.), make sure that you disconnect the power supply



## Ozone Time Setting Chart

Different food items are required to be purified for different period of time. Please select the appropriate time as per the chart below.

Vegetables		
Assortments	Time Setting	Benefits
Lotus Root, Taros, Ginger and Bean Sprouts	15 Minutes	Reduces harmful chemicals, odour, bacteria and viruses from vegetables
Onion, Cucumber, Tomato, Cabbage, Radish, Carrot, Lettuce, Peas, Leek and Green Vegetables	30 Minutes	
Fruits		
Assortments	Time Setting	Benefits
Strawberry, Grapes and Apple	30 Minutes	Oxidizes harmful bacteria, viruses and pesticides from fruits
Lemon, Water Melon, Grapes, Banana, Orange and Salads	15 Minutes	
Seafood & Meat		
Assortments	Time Setting	Benefits
Crab, Squid, Shark/ Ray Fish, Squid Prawns, Sprats and Meat	30 Minutes	Eliminates deadly pathogens, smell, and germs from seafood and meat
Cereals		
Assortments	Time Setting	Benefits
Rice, Barley, Oats, Pulses and Grains	15 Minutes	Removes pesticides, cysts and germs from the cereals


## Troubleshooting

No.	Breakdown	Reason and Troubleshooting
1.	The LED Light is not flashing and the device is not functioning	Ensure that the plug has been properly connected to the power supply and the on/off switch has been pressed properly.
2.	Amplitude vibration and loud noise	If the device is being used in an upright position, then it should be kept at a 5mm distance from the wall. Drill the screws (on the wall) in an even position. If it is not possible, then place a rubber pad between the device and wall.
3.	Weak output pressure	Make sure that the Silicon Tube is fully connected and is not bending.

## Caution

- Do not spray ozone air directly on your face.
- Do not spray water on the device to prevent damage, fire and electric shocks.
- Keep the device away from heat or high temperatures.
- Do not use the device in an airtight room.
- Keep the device away from children.
- The device uses high voltage current. Please do not open and repair it by yourself.
- If the device breaks down, do not try to repair the device by yourself.
- Remember to clean the device with a soft, dry fabric on a weekly basis.
- Unplug the device if you are not using it for a long period.
- Refer to the above items for cleaning and maintaining the device.
- This appliance is not to be used by children or any person with reduced physical, sensory or mental capability or lack of experience and knowledge, unless they have been given supervision or instructions.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

## Technical Specifications

Product	KENT Ultima Vegetable Cleaner
Product Code	111115
Product Generic Name	Vegetable Cleaner
Product Colour	White
Voltage	Single Phase 220-240 V AC, 50-60 Hz. 
Rated Power Dissipation	13W
Time Setting	15 min-30 min.
Ozone Output	200 mg/hr.
Size (mm)	405 (L) x 330 (W) x 470 (H)
Weight	5.6 kg
Noise	≤ 45 dB (A)
Output Pressure	≥ 0.15 kg/cm <sup>2</sup>
Condition Temperature	0°C to 40°C