KENT
House of Purity

Marketed by:
KENT RO SYSTEMS LTD.
E-6, Sector-59, Noida, U.P.-201 309, India.
E-mail: sales@kent.co.in I Website: www.kent.co.in

Made in India


KENT

SUPER STAND MIXER

IDEAL PARTNER TO WHISK, MIX & KNEAD

KENT
House of Purity

Instruction Manual





Whisk

Dough Hook

Beater



Welcome to KENT

Dear Customer,

Congratulations on your purchase and welcome to **KENT!**

At the outset, allow us to thank you for your trust in KENT Smart Chef Appliances. At KENT, we take pride in our reputation for quality products and industry proven performance. We are certain that you will be more than satisfied with **KENT Super Stand Mixer** and that it will serve you and your family's needs without any compromise.

This guide will help you in getting the best out of your appliance. Please go through the booklet to familiarise yourself with the operation and the maintenance of the product. With its robust and high quality build, you can look forward to years of trouble-free service.

To ensure that the warranty of your appliance is effective, it is important that you fill the enclosed warranty card and mail it to us within 15 days of purchase.

In case you require any further information, please contact your nearest KENT dealer or branch.

Bon Appètit!

KENT RO Systems Ltd.

TABLE OF CONTENTS

1. Introduction 1
2. Features of KENT Super Stand Mixer 1
3. Know Your Product 1
4. Items in the Box 2
5. How to Operate 2
6. How to use the Accessories 3
7. Cleaning and Maintenance 3
8. General Safety Instructions 3
9. Troubleshooting 4
10. Technical Specifications 5

INTRODUCTION

We, at KENT, have always believed that a clean and healthy life is the right of every individual. This ethos is what made us embark on the journey to develop innovative solutions for purifying the water that we drink, the vegetables and fruits that we eat, the homes we live in, and the air that we breathe and much more.

Use of innovative technology and support from a competent service network have enabled us to create a brand that has become synonymous with well-being and health. Continuing with this tradition, we now present the **KENT Super Stand Mixer**, your ultimate kitchen companion for effortless and efficient mixing, kneading, and whisking.

With its powerful motor and versatile attachments, this stand mixer brings professional-grade performance to your home, making delicious baked goods, perfect dough, and fluffy meringues easier than ever. Designed with a sleek, modern aesthetic and user-friendly controls is not just a tool, but a statement piece for your kitchen.

Elevate your culinary creations with the power and precision of KENT.

FEATURES OF KENT SUPER STAND MIXER

1. **KENT Super Stand Mixer delivers powerful performance with 1300 W and 100% Copper Motor.**
2. Large capacity of 5 L bowl made of food grade SS304.
3. 6 speed settings & pulse function for efficient whisking, mixing & kneading.
4. Low RPM does not generate heat and keep nutrients intact.
5. Anti-spill splash guard with pour spout.
6. Lifting mechanism with safety switch.
7. Vibration absorption design, no displacement during operation.
8. LED indicator light for decoration.

KNOW YOUR PRODUCT




ITEMS IN THE BOX


1. **KENT Super Stand Mixer** : 1 N
2. Whisk : 1 N
3. Dough Hook : 1 N
4. Beater : 1 N
5. Splash guard : 1 N
6. **Warranty Card** : 1 N

HOW TO OPERATE

1. In order to lift the arm, press the Rise button (Fig 2) downwards in the direction of the arrow. The arm will now move upwards.
2. Place the mixing bowl into its holding device and turn the bowl clockwise until it locks into place.
3. Mount the required utensil (Dough hook or Beater or Whisk) by inserting the top into the output shaft, and turn anti-clockwise until it locks into place (Fig 3 & 4).
4. Now fill in your ingredients.
5. Lower the arm using the rise button.
6. Place the splash guard into its body.
7. Switch the machine using the speed button to a speed between 1 and 6.
8. For pulse function (kneading at short intervals), turn the switch to the "PULSE" position. The switch has to be held in this position according to the desired interval length. When the switch is released it returns automatically to the “0” position.
9. Press the rise button downwards and the arm will be raised.
10. The mixture can now be released with the help of a spatula and removed from the mixing bowl.
11. The mixing bowl can now be removed.



HOW TO USE THE ACCESSORIES

Use	Image	Levels	Time (Min)	Maximum Quantity	Operation Method
Dough hook		1-3	5	600 g Flour and 320 g water	1 speed run for 30 sec, the 2 speed run for 30 sec, and then the 3 speed run for 2 min to 4 mins to form a cluster
Beater		2-4	3	Total less than 2 kgs	2 speed run for 20 sec, the 4 speed run for more than 3 min
Whisk		5-6	3	At least 3 egg whites	Use 5 or 6 speed to run 3 min above

Note: With heavy mixtures do not operate the machine for more than 6 minutes, and then allow it to cool down for a further 10 minutes.

CLEANING AND MAINTENANCE

1. Before cleaning please switch off the power supply and unplug it.
2. Do not immerse the entire KENT Super Stand Mixer in water or other liquids for cleaning to avoid electric shock hazards or malfunctions.
3. Use a neutral detergent to clean the product and all its accessories.
4. Use a damp soft cloth to clean the outside of the housing.

Note: The accessories are not dishwasher safe.
After cleaning, allow the accessories to dry thoroughly before reassembling the device.
Apply a small quantity of vegetable oil on the accessories after they have dried.

GENERAL SAFETY INSTRUCTIONS

1. This appliance is suitable for indoor use only.
2. Operate the appliance on a flat surface.
3. Unplug the appliance when not in use and before servicing.
4. Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
5. When cleaning, unplug the appliance and if the appliance is not in use remove the attached accessories.
6. Check the appliance for any damages in the power cord. Do not use the appliance if the power cord is damaged. Do not try to repair it on your own.
7. Keep it out of the reach of children.

TROUBLESHOOTING

NO.	TROUBLES	SOLUTION
1	The machine doesn't work	Check if the plug is properly connected in the socket. Check if the rise button springs back in place. Check if the machine works continuously for more than 6-10 mins, and wait until the motor cools down.
2	Noise in the mixing bowl when working (the accessory scrapes the bowl)	Check if the mixing bowl is properly installed. Check if the accessory is installed properly on the machine.
3	The splash guard doesn't fit the mixing bowl properly	Check if the splash guard is placed on the machine properly. Check if the mixing bowl is installed properly on the machine and locked correctly.
4	The machine doesn't work on certain speed	Check if the mark on the speed knob corresponds to the speed marked on the appliance. Rotate the speed knob to 0, and re-check if the machine works to the speed marked on the appliance.
5	Movements when the machine working	Check if the anti-slip feet fall off. Check if the machine is placed on a smooth and flat tabletop.
6	The rise button didn't spring back in place after installing the mixing bowl and pot cover	Check if the splash guard is placed on the machine properly. Check if the mixing bowl is properly installed.

TECHNICAL SPECIFICATIONS

Product	KENT Super Stand Mixer
Product Code	116211
Net Weight	3.6 kg
Input Power Supply	Single Phase 220-240 V AC, 50 Hz. ⧈
Power Consumption	1300 W
Product Dimensions	350 (L) x 223 (W) x 293 (H) mm
IP Rating	IPX0

For BIS certification details please visit www.bis.gov.in

Note: KENT RO Systems Limited is registered under the Plastic Waste Management (PWM) Rules, 2022 with EPR authorization No. BO-29-UTT-04-AADCK0743L-23 (Brand Owner) & IM-20-000-09-AADCK0743L-23 (Importer) for Category-II plastic packaging (thickness above 50 microns).